




Model:BM-H215/215HDR/245

BM-H



User Manual

Please read this user manual throughout before using

Ver:A

Declaration

- Any internal technology (including hardware equipment, software design and product trademark) of the product shall be protected by law, and any infringement of intellectual property rights of the product shall be investigated for legal liability.
- All the brand and trademark in this product are protected by law,all other company's brand and trademark in this product are protected by their owner's law.
- In order to better service majority users, SWIT products will keep improving and developing, SWIT keep the right to revise and improve this user manual without previous notice.
- The warranty period of this product are two years, the following condition are not covered by the warranty:
 - (1) The appearance and the LCD panel are damaged by man-made out force;
 - (2) The amount of defective pixels are under three;
 - (3) Damage the product by using incompatible power adaptor;
 - (4) Damage the product due to violation operation;
 - (5) Disassemble the product when using;
 - (6) Other faults or damages not caused by design ,technology,manufacture and quality.
 - *Any sales person have no right to provide extra warranty beyond these terms.
- If you have any advises or requirements about our products during using, please feel free to contact with us via phone or E-mail.
- This manual is applicable to all models of BM-H monitors. The schematic diagram of BM-H215 is taken as an example. Any specification, appearance of the different, this manual will be attached with text.

SWIT Electronics Co., Ltd.

Address: 10 Hengtong Road, Nanjing Economic and Technological Development Zone,

Nanjing 210038, P.R.China

Phone: +86-25-85805753 Fax: +86-25-85805296 Email: contact@swit.cc http://www.swit.cc

Maintaince percautions

Warning

- 1. To reduce the dangerous of fire or electric shock, do not expose the monitor in raining or wet place.
- 2. The monitor will create noise when using near high-intensity magnetic field.

Precautions for power supply

- 1. Please use the special power adapter specified by the original factory to avoid damage to the product.
- 2. If other DC power supply is used, ensure that the voltage range, power supply and polarity of the power supply meet the requirements.
- 3. In the following cases, please unplug the power cord and external battery of the product:
 - (A) If you have not used the product for A long period of time.
 - (B) If the power cord or power plug/socket is damaged.
 - (C) If the product is hit or dropped so that the shell is damaged.

Precautions for product use

- 1. Please do not touch the screen surface directly with your fingers to avoid damage to the screen, and the oil on the skin will be difficult to remove if left on the screen.
- 2. Please do not put pressure on the LCD screen, LCD screen is very delicate and fragile.
- 3. Do not place the product in an unstable place, as the product may be seriously damaged due to falling.

Precautions for product cleaning

- 1. Clean LCD screen, please use dry soft fabric with fluff and special liquid crystal cleaning agent, to remove dust and stains on the screen.
- 2. Do not pressure when wiping the LCD screen surface.
- 3. Please do not use water and other chemical cleaners to wipe the LCD screen surface, chemical agents may damage the LCD screen surface.

Contents	
Declaration	. 2
Precaution	. 3
Content	4
Packing list	4
Introduction	4
Description	- 5
Front panel	. 5
Back panel	7
Display information	8
Setting	11
Dimension	23
Specification	24
Trouble shooting	27

Packing list

No.	Standard accessories	Quantities
1	Monitor	×1
2 User manual		×1
3	Warranty card	×1
4	Battery plate (A & S)	×1
5 Monitor stand		×2
6	Power cable	×1

Introduction


This series of monitors adopt LCD panel, the resolution is up to 1920×1080 , H178° / V178° ultra-wide viewing angle, supports 1 channels of 12G/6G/3G/HD/SD-SDI and has 1 channels of 3G/HD/SD-SDI, and 1 channel of HDMI 2.0, and has 1 channels of 3G/HD/SD-SDI, 1 channels of 12G/6G/3G/HD/SD-SDI ring out, with earphone and speaker output.

Features:

- 1920 × 1080 IPS LCD Panel
- 4K/UHD interface, (1x12G-SDI&3x3G-SD Input, 2xSDI output, 1xHDMI 2.0 Input)
- 16ch audio bar display, with any selected 2ch output
- Support waveform selection display Y/Cb/Cr/R/G/B /RGB and single line selection mode
- Vector scope, R/G/B/Y histogram, bi-color focus assist
- 3DLUT (17 x 17 x 17) accurate color correction
- Dynamic UMD and TALLY(TSL3.1, 4.0) display
- Composition ratio auxiliary line:4:3/13:9/14:9/15:9/16:9/1.85:1/2.35:1/2:1/2.39:1/Custom 1/Custom 2
- Support USB firmware upgrade and import Log file.(USB file system supports FAT 32 format only)
- Support ECO mode

Operation Instructions

· Front panel




- (1) **Speaker**: For SDI/HDMI embedded audio. (Will not work if earphone is plugged in)
- (2) **F1~F5 function keys:** Customize shortcut function keys. Users can set the shortcut keys to different functions according to their own requirements.
- (3) **User1~User4:** User shortcut key, which can be used to quickly enter the set user mode. Long press to save user settings. Please see details in "9. System"
- (4) **INFO:** Display setting item. Press "INFO" button to display or turn off relevant status information and audio and video analysis function graph. When opening the menu, press "INFO" to exit the menu with one click

(5)

Brightne	ss Contrast	Saturation	Brightness: Adjust the brightness100~100 adjustable, default value is 0. Contrast: Adjust contrast100~100 adjustable, default value is 0.			
			Saturation: Adjust saturation100~100 adjustable, default value is 0.			
Backligh	t Volume	Source	Backlight: Adjust the backlight. 0~100 adjustable, default value is 16.			
			Volume: Adjust the volume.0~100 adjustable, default value is 36.			
this opt and aut light wil	Press Brightness, Contrast, Saturation, Backlight, Volume five shortcut keys confirm to select this option, and rotate Menu to adjust the corresponding item value directly. Press the button and automatically cancel the selection without operation within five seconds, and the button light will be off, long press to restore default values; Adjust the volume.0~100 adjustable, the default value is 36.Long press the volume button to mute.					
	Source	7	Source: Select the input source signal format.			
	SDI 1 SDI 2 SDI 3 SDI 4 4xSDI SQD 4xSDI 2SI HDMI Multiview					

- (6) **Menu/Enter**: When no Menu is displayed, press the button directly to open the Main Menu; Rotate the knob to select different settings or adjust parameter values, press the knob to set;
- (7) **LUT/Firmware**: Update firmware or import LUT files;
- (8) **PHONE**: 3.5mm headphone jack is used to monitor the embedded audio signals of SDI and HDMI;
- (9) **Power**: Power switch;
- (10) **Tally lamp**: You can select the color of the tally lamp from "Green", "Red", or "Yellow".

· Rear panel



(1) **SDI1 IN&OUT**:12G/6G/3G/HD/SD-SDI

(2) **SDI2 IN&OUT, SDI3 IN, SDI4 IN**: 3G/HD/SD-SDI

(3) **ETHERNET(Network interface)**: 1000M high-speed RJ45 Ethernet port, for web external control

(4) **HDMI 2.0 IN**: Will not display HDCP protected content

(5) **RS485**: TSL UMD control port

(6) **GPI**: GPI control port

(7) Fan


(8) VESA bracket mounting area

(9) **DC IN:**12V~17V

(10) **AC IN:**100V~240V

(11) Battery plate

· OSD



(1) Time Code (SDI)

Under SDI input, the monitor can display Time code information (LTC, VITC1&2). If no Time code info is detected, it will display "TC UNLOCKED". User can set function keys F1~F5 or GPI pins as "Time Code" to turn on or off this function.

(2) Surround

The default channel of surround is 5.1 channel 7 & 8

(3) On screen TALLY

Display TALLY signal from GPI control port.

(4) Source ID/UMD

Display /UMD (TSL3.1/4.0), user can set in the UMD menu

(5) Color checker

After auto calibration, the color gamut and chromatic aberration (\triangle E) before and after the color correction pop up. "Auto Calibration" -"Measure" pops up the gamut value and color difference value (\triangle E) of the previous calibration and this measurement.

(6) Audio VU/PPM meters

Display meters of SDI/HDMI embedded audio or analog audio. The audio meter display channels, on screen positions and background blending are adjustable. can be set in the submenu of "Audio setting". User can set function keys F1~F5 or GPI pins as "Audio Bar" to turn on or off this function.

(7) Histogram

User can set function keys F1∼F5 or GPI pins as "Histogram" to turn on or off this function.

(8) Vector

User can set function keys F1~F5 or GPI pins as "vector", The vector scope pattern display positions,

colors, background are adjustable. Turning on the gamut map in the case of turning on the vector map can display the gamut ratio of the signal image under DCI-P3/REC709/REC2020

(9) Waveform

User can set function keys F1∼F5 or GPI pins as "Waveform" to turn on or off this function.

Key configuration

Steps

- 1. Press "Menu/ Enter" button, the main menu will pop up from the left top of the screen. The selected main menu highlights in yellow.
- 2. Revolve "Menu/ Enter" to select submenu, the selected submenu highlights in yellow, press "Menu/ Enter" to apply and enter into the selected submenu's items.
- 3. Revolve "Menu/ Enter" to select the item which needed to adjust, press "Menu/ Enter", the selected item and its parameters will be highlighted in yellow
- 4. Revolve "Menu/ Enter" to change the selected item's parameter, press "Menu/ Enter" to apply and save the settings.
- 5. Revolve "Menu/ Enter" to select "Exit", press "Menu/ Enter" to quit submenu. Select "Exit & Status" under the Main Menu and press to quit Main Menu

% Notice

- * The items in gray cannot be set up
- * If there is no operation under the set time, the menu will automatically save settings and quit.
- * If the key inhabit function is turned on, except System menu, all other items are in gray. Please turn off the key inhibit function to adjust the items.

Menu Configuration

Menu configuration introduces the main menu and each sub-menu. Menu items marked * will give more detailed menu description or operation explanation after the list

1.Exit&Status—Exit the main menu and display the current status of the monitor

Press "Menu/Enter" to bring up the main menu in the top left corner of the screen, the main menu shows the current working status of the monitor.

(1) Format

The current input signal standard is displayed; if there is no recognisable signal input, "No signal" is displayed. When multi-screen is selected for the current channel, the standard of the input signal for each of the four SDI 1/2/3/4 channels is displayed.

Main Menu		S	tatus	
Exit&Status		Format	>	xx—
Input	>	Source	>	xx
Picture	>	Color Temp	>	XX
Color Management	>	F1	>	XXX — (
Scanning	>	F2		XXX
Control	>	F3		XXX
Assist	>	F4		XXX
De-embed	>	F5		XXX
Auto Calibration	>	Profile Type	>	XX (
System	>	Version	>	XX (
Multiview Setting	>			

(2) Input source

Displays the currently selected channel.

(3)Colour temperature

Displays the currently set colour temperature mode

(4) Function key 1 to function key 5

Displays the function value of the current function key setting

(5) Model

Shows the current monitor model

(6) Versions

Shows the current software version number

2.Input—Set the color of input video

Menu Item	Menu description	Value
		Full 0-1023、
Input Range*1	Set the input range of input video	SDI Full 4-1019、
		Limited 64-940
Red Gain	Adjust Red Gain	-100 ~ +100
Green Gain	Adjust Green Gain	-100 ~ +100
Blue Gain	Adjust Blue Gain	-100 ~ +100
Red Bias	Adjust Red Bias	-100 ~ +100
Green Bias	Adjust Green Bias	-100 ~ +100
Blue Bias	Adjust Blue Bias	-100 ~ +100
Reset	Reset the gain and bias values of the settings	/

^{*1} Quantization range: Sets the quantization range of the video to suit the input video signal. The default video quantization range is Limited 64-940 for the broadcast application.

3.Image setting—Setting for the picture preference

Menu item	Menu description	Value
Contrast	Adjust contrast	-100 ~ +100
Brightness	Adjust brightness	-100 ~ +100
Saturation	Adjust saturation	-100 ~ +100
Sharpness	Adjust sharpness	0 ~ +100
Backlight	Adjust backlight	0 ~ +100

4.Color Management—Setting about video colors

Menu item)	Menu Description	Value
Color gamut	t *1	Set gamut values	LCD Native,DCI-P3,Rec.709,Rec.2020
Gamma*2		Set gamma values	1.0,1.8,2.2,2.4,2.6,PQ1000,HLG1000,S-Log3
	HLG System Gamma *3	Set HLG System Gamma	1.0,1.1,1.2 (default) ,1.3,1.4,1.5
Gamut and gamma values are	D-Log to 709	Set gamut to Rec.709 camera table	OFF,J-Log1,Log-C,S-Log2,C-Log,V-Log,RedLogFilm, S-Log3,User-Log
set to menu items with specific values	D-Log to PQ	Camera table when gamut is set to Rec.2020 and gamma value is PQ1000	OFF, ARRI_LogC_PQ, Canon_CLog2Cin_PQ Canon_CLog3Cin_PQ, Panasonic_VLog_PQ, RED_L3G10_PQ, Sony_SLog3_Cin_PQ, Sony_SLog3_SG3_PQ
	D-Log to HLG	Camera table when gamut is set to Rec.2020 and gamma value is HLG1000 Rec.2020 and gamma value is HLG1000	
Multi gamut	*4	Multi-colour gamut on, off	OFF,ON
Color temp		Set screen display colour temperature values	D55, D65, D75, D93, DCI, USER1, USER2
User temp		Set the user color temperature value when the color temperature mode is selected as "USER 1/USER2"	4000K~9800K
G/M		Set the user color temperature value when the color temperature mode is selected as "USER 1/USER2"	-100 ~ +100
LUT import*	5	Select the cube file you want to import	None, 3DLut.cube, User-Log.cube
Reset LUT		Select the appropriate cube file to restore to factory settings	NO, 3DLut.cube

*1 Color gamut

Set the gamut to match the input audio.

*2 Gamma

When Four-screen is selected; the gamma of four signals can be adjusted separately for display

*3 HLG System Gamma

Display tunable only when Gamma is set to HLG1000

*4 Multi-colour gamut

Individual colour gamut for multi-colour gamut, gamma can be adjusted individually, multi-colour gamut default colour gamut Rec.2020, gamma 2.2.

*5 LUT import

Place the cube file that needs to import the monitor in the root directory of the u-disk, insert the u-disk into the USB interface on the front shell of the monitor, and choose to import the corresponding file

5. Scanning—Setting for picture scan, zoom, etc.

Menu Item	Menu Description	Value
Scanning*1 Set up a scanning mode that matches the audio to the screen Pixel,		Pixel To Pixel, Panel Fit, Native
Zoom Mode*2	Set a zoom mode	OFF, Top Left, Top, Top Right, Left, Center, Right, Bottom Left, Bottom ,Bottom Right
Freeze Frame	Select an image still mode	OFF, ON
Odd/Even Frame*3	Set to open odd field or even field	OFF, Odd Frame, Even Frame

- *1. Scanning Panel Fit: Turn on this feature to adapt the video to the entire screen.

 Native only displays the original mode in the specified mode.
- *2. **Zoom mode:** Shown below, the image is divided into 9 regions and adjusted to display in sequence.

Top Left	Top Center	Top Right
Center Left	Center	Center Right
Bottom Left	Bottom Center	Bottom Right

When the zoom mode is turned on, a rectangle box pops up at the bottom left of the screen, showing the currently selected zoom image area; Open Low Latency Mode, Zoom mode function is turned off.


*3.Odd/Even Frame Odd/Even Frame is only displayed in I mode. Open Low Latency Mode and Odd/Even Frame function is turned off.

6.Control—Setting for TALLY, UMD, IP control to the monitor


Menu Item	Menu Description	Value	
GPI Control *1	Open or close GPI Control	OFF,ON	
GPI 1Pin		SDI1, SDI2, SDI3, SDI4, 4×SDI(2-SI)、	
GPI 2Pin		4×SDI(SQ), HDMI, Red Tally, Green Tally,	
GPI 3Pin	Set the function of each	Yellow Tally ,Time Code, Freeze Frame,	
GPI 4Pin	pin for GPI terminal	WFM Type, WFM Single Line, UMD, Marker , Waveform, Audio Bar, Zebra,	
GPI 5Pin	-	Vector, Low Latency Mode, Histogram,	
GPI 6Pin	-	Focus Assist , False Color	
Tally Setting	Switch on/off Tally light	OFF, ON, Blinking	
Tally Position	Set the display position of On Screen Tally Lamp	Top, Bottom	
F1		Time Code, Color Temp, Freeze Frame ,	
F2	Sat the control function of the	Waveform, Waveform Type, UMD, Marker,	
F3	Set the control function of the	H/V Delay, Blue Only, Audio Bar, Zebra,	
F4	function key	Vector, Low Latency mode, Histogram,	
F5	_	Odd/Even Frame , Focus Assist ,False Color,CIE	
UMD *2	Open or close UMD display	OFF, ON	
UMD Color	Set the color of UMD characters	White,Red,Green,Blue,Black,Gray	
UMD Position	Set the position of UMD characters	Top,Bottom	
UMD Size	Set the size of UMD characters	Large, Small	
UMD Blending	Show the transparency of the UMD background	OFF, LOW, HIGH	
Display Type	Set display UMD or source name characters	Source ID, TSL3.1,TSL4.0	
RS485 Address	Set the location of RS485	1~126	
Baud Rate	Fixed for 115200	115200,8,n,1/38400,8,n,1/9600,8,n,1	
Source ID	Set the character that the source name displays	A-Z, a-z, 0-9, [\]^_`{l}~@?>=<,,/+* ()' &%\$#''!	

*1 GPI control

Connect the GPI remote control terminal through the GPI interface on the real panel of the monitor, turn on "GPI control" and set the function of GPI 1-6 buttons.




The GPI control allows you to control both the Tally light and the on screen TALLY light at the same time:




*2 UMD

Select the display type as "UMD", which can be controlled with TSL UMD.



Pin No	RS 485 IN	RS 485 OUT
1	GND	GND
2	NC	NC
3	RXD-	RXD-
4	NC	NC
5	NC	NC
6	RXD+	RXD+
7	TXD-	TXD-
8	TXD+	TXD+

Cascade:




7. Assist— Setting for Vector scope and Histogram patterns.


Menu Iter	m	Menu Description	Value
False Color		Turn false color display on or off	OFF, ON
Blue Only		Turn blue only on or off	OFF, ON
Focus Assist		Turn on or off focus assist and adjust the color of the focus assist	OFF, Blue, Red
Zebra		Turn zebra on or off	OFF, ON
	Waveform	Turn waveform on or off	OFF, ON
	WFM Type	Set the WFM Type	Y, Cb, Cr, R,G,B,RGB
	WFM Position	Set the WFM position	Bottom Left, Bottom
Waveform	WFM Blending	Set the blending of the background color of the waveform	Right, Top Left, Top Right OFF, High, Low
	WFM Brigh	Set the brightness within a WFM image	Low, Medium, High
	WFM Color	Set the color of the waveform displayed on the waveform chart	White, Green, Color
	WFM Single Line*1	Switch on single line waveform	OFF, ON
	WFM Line Count	Set a line for the single line waveform	1-1080
	Vector	Turn vector on or off	OFF, ON
	Vector Position	Adjust the position of the vector on the screen	Bottom Left, Bottom Right, Top Left, Top Right
Vector	Vector Blending	Vector scope transparency selection	OFF, LOW, HIGH
	Vector Brigh	Set the brightness within a vector image	Low, Medium, High
	Vector Color	Set vector colors	White, Green, Color
	CIE	Turn the colour gamut chart on or off	On,Off
	CIE Position	Adjusting the position of the colour gamut map on the screen	Top left, Top right, Bottom left, Bottom right
CIE	CIE Blending	Set the transparency of the background colour of the colour gamut map	Off, Low, High
	CIE Bright	Set the brightness within the colour gamut map chart	Low, Medium, High
	CIE Color	Set gamut map colours	White, green, colour
	Histogram	Turn histogram on or off	OFF, ON
Histogram	Histogram Position	Set the display position on the histogram screen	Top left, Top right, Bottom left, Bottom right
	Histogram Blending	Set the transparency of histogram background color	OFF, LOW, HIGH
	Marker	Turn marker on or off	OFF, ON
	Marker Select	Set the scale of the market line	16:9,15:9,14:9,13:9,4:3,2. 35:1,2:1,1.85:1,2.39:1, Custom1, Custom2
	Horizontal*2	Set the X – axis value of the marker	50%~99% (0~1920)
Marker	Vertical	Set the Y – axis value of the marker	50%~99% (0~1080)
	Safety area	Set safety area percentage	80%~100%
	Fit Marker	Set safety area to fit marker ratio or not	OFF, ON
	Center Marker	Switch on the center cross marker	OFF, ON
	Marker Color	Select a color for marker	White, Red, Green, Blue, Black, Gray
	Marker type	Set the display type of marker	Type 1, type 2
	Marker background	Marker outside color setting	OFF, Black, Gray
Eye pattern		Turn eye pattern on or off	ON,OFF

*1 WFM Single Line

Open waveform single-line mode, the monitor shows only one line of audio waveform. Rotate the Menu/Enter knob to select the number of lines of audio signal to display the waveform. (The selection range of the number of lines in a waveform depends on the current signal standard)



WFM Single Line:OFF



*2 X-axis/Y-axis position

When marker select is USER 1, Users can adjust the X position and Y position of the marking line according to their own needs, Coordinate value is adjustable from 50% to 99%; when marker select is USER2, the value of X-axis is adjustable between $0\sim1920$, the value of Y-axis is adjustable between $0\sim1080$.

*3 Eye pattern

Only SDI1 supports eye diagrams.


8. De-embed— Setting for video/audio analysis functions

Menu Item	Menu Description	Value			
	Audio Meter	Turning audio meters on or off	ON,OFF		
	Audio meter Position	Adjusting the position of the audio meter on the screen	Top Left, Top Right, Bottom Left Bottom Right		
Audio Meter	Audio meter Blending	Set the transparency of the audio meter background colour	OFF,LOW,HIGH		
	Audio meter marker *1	Setting the audio meter marker line	ON,OFF		
Lieggious	Lissajous Pattern	Turn on or off Lissajous figure	ON,OFF		
Lissajous	Lissajous position	Set the position of the Lissajous position on the screen	Top Left, Top Right, Bottom Left, Bottom Right		
	Surround Phase	Turn surround Phase on or off	ON,OFF		
Surround	Surround Position	Adjusting the position of the surround sound display on the screen	Top Left, Top Right, Bottom Left Bottom Right		
Phase	Surround type	Selecting the type of surround sound	5.1,		
	Surround Blending	Set the transparency of the surround sound background colour	OFF,LOW,HIGH		
Left Channel*2	Select the left channel output channel	Channel 1~16			
Right Channel	Select the right channel output channel	Channel 1~16			
Volume	Adjust audio volume	0~100			
Volume	Adjust audio volume	0~100			
Time code	Turn on/off Time code	OFF, ON			
H/V Delay*3	Turn on/off H/V Delay	OFF, ON			

*1. Audio meter marker

Audio table display, display 16 channel audio table Type1: Only the audio table is displayed Type2: Display audio decibels, audio alarm signal and left and right channel options

Type 1



*2. Left Channel/ Right Channel

Audio meter under SDI showing 16 channel audio meter Audio meter under HDMI, menu shows 8 groups of channels

*3 H/V Delay

H/V Delay is not displayed on HDMI channel.

9. Auto Calibration*1

Menu Item	Menu Description	Value
Probe Select *2	Select a probe to use	X-rite l1 Pro OEM, Jeti Specbos 1211
Start Calibration*3	Select whether to start calibration	No/Yes
Measure*4	Test current color	No/Yes

*1.Auto Calibration

The monitor has 3D LUT calibration software built-in, and supports the following color sensor probe to directly plug into front USB port. When start calibration, the monitor will generate standard colors and the color sensor will read the colors one by one and upload result to the monitor by USB connection. The monitor will comparing the generated colors and sensor read colors, to work out 3D LUT cube and calibrate itself automatically.

*2.Probe Select


This monitor supports the following probes models:

BRAND	MODE
X-rite	I1 Pro OEM (SWIT OEM)
JETI	Specbos 1211

*3.Start Calibration

Steps:


- 1, Put the monitor into a dark room. Switch on the monitor.
- 2. Connect the calibration instrument (compatible with x-rite and JETI color measuring instruments) and monitor via USB. Before calibration, ensure that the monitor and the color calibration instrument are in good condition and the monitor aging time reaches 30 minutes.
- 3, Enter the "Probe Select" and select the currently used calibration probe.
- 4. Enter the "Start Calibration" and select "yes" to start calibration. The monitor will display the prompt message and the color position prompt box. Put the sensitive part of the device in the color position prompt box correctly. Note that when placing the calibration instrument; do not squeeze the monitor's LCD screen.



- 5. Select "yes" to begin auto calibration. The color calibration instrument will automatically measure the color of the screen and correct the color of the screen. During this process, it is necessary to observe the color calibration progress bar in the color correction prompt box.
- 6. Press "INFO" to terminate the color correction process at any time. When the prompt color calibration progress reaches 100%, the whole automatic color calibration is completed. After automatic color correction, press the "INFO" button to exit the menu and let the monitor enter the normal display mode.

7、After the automatic color correction, the display screen pops up "Before Calibration" and "After

Calibration".




*4. Measure

The monitor has been calibrated in factory. And may need to be re-calibrated after a period of time. Before re-calibrated, the measure function can check the current color to compare with the last time calibrated color, to decide if the monitor needs to be re-calibrated. Connect with the sensor probe and place the sensor probe onto the right position like calibration step. Enter "Auto Calibration" –

"Measure".

The monitor will generate several colors and finish measure within 30 seconds. And display the result as:



10. System— User profile saving, firmware update.

Menu Item	Menu Description	Value
Key Lock *1	Set lock key	OFF, Full Lock
Recall Profile*2	Select make user mode current	Factory,USER1,USER2,USER3,USER4
Save Profile	Save the current state as a user setting	USER1,USER2,USER3,USER4
Payload ID	When turned on, Payload ID information conforming to SMPTE ST 352 standard is automatically adapted	OFF, ON
Low Latency Mode	Open or close low latency mode	OFF, ON
Green mode	Set the display mode of green mode	Black Backlight, Gray Backlight
Idle Duration	Set how long it will be in the no-signal state and turn on green mode	30 Sec, 1 Hour, 2 Hours, 4 Hours, OFF
IP*3		192.168.001.200
Net Mask	Set up the monitor IP address to achieve remote web	255.255.255.000
Gateway	control	192.168.001.001
Port(1024~65535)		08080
OSD TIME	Set OSD display time	5~180
Key Brightness	Set the brightness of the key lamp	OFF, Low, High
Language	Select Chinese or English language to display	Chinese, English
System Reset	Reset all Settings in the menu system	No/Yes
Update *4	Set whether to upgrade firmware	No/Yes

*1.Key Lock



The "Menu/Enter" button can be operated when the button is locked. "Key Locked" will be displayed on the screen when you press the Locked button or knob.




*2. Recall Profile/Save Profile

User Settings provide 4 menu Settings, that is, users can save the current monitor menu Settings as one user Settings (USER1~USER4) according to usage habits. Then, when switching menu Settings, just select the corresponding "USER1~USER4" through the "Recall Profile" item to display the corresponding menu Settings. Example: By adjusting the parameters of the color temperature of 2200K, open the necessary auxiliary functions (such as: histogram), set the function key to the desired menu (such as F1 is set to "Blue Only"), and so on, the monitor Menu Settings can be "USER Settings" save as "USER" 1, rotating the "Menu/Enter" choose to load the USER Settings "set to the current" USER 1 "mode, the monitor Menu item value will show" USER 1 "mode to save Menu.

*3. IP control

Connect the monitor to the LAN through an ETHERNET interface, and the Monitor can be controlled by web page.



Pin No	Pin Name
1	TX+
2	TX-
3	RX+
4	
5	
6	RX-
7	
8	

Enter Menu- System – IP/Net Mask/Gateway/Port to set the monitor address. Set the computer Ethernet IP addresses at the same LAN environment as the Monitor. Launch any of a web browser on the computer, and enter URL: Monitor IP+ Port (Example: 192.168.1.99.8080). The web server control page will be displayed.





Fig1:IP Address setting

- Used crossed wired cable for computer-monitor directly connection.
- Use straight-through wired cable for Router connections.
- Please seek help from your webmaster for any network connections.

Webserver page control interface

SWIT.



*4.Upgrade

System software can update by USB interface, and steps are as follows:

- 1.Download the latest software package into the U-disk root direction.
- 2. Open the monitor and plug U-disk into USB into port.
- 3. Follow the step "Menu-System-Update", the monitor will update automatically.
- 4. When update finishes, press "Power" button, close and reboot the monitor.

FIRMWARE UPDATE

Please put the firmware file into USB disk root directory,and Prese MENU to start!

MENU:OK

INFO: Quit

Remark

- 1. Only copy one model and software version into the U-disk root direction.
- 2. Never shutdown the power during the update progress.

11. Multiview setting*1

Menu item	Menu description	Value	
Multiview type*2	Select multiview type	Quad View、PBP、PIP	
DIC1	Select channel 1 when set to Quad	CD11 CD12 CD12 CD14 HDM	
PIC1	view or PIP	SDI 1, SDI 2, SDI 3, SDI 4, HDMI	
PIC2	Select channel 2 when set to Quad	SDI 1、SDI 2、SDI 3、SDI 4、HDMI	
1102	view or PIP		
PIP Window position	Select PIC2 position when set to PIP	Bottom Left、Bottom Right 、Top	
	Sciectificz position when set to i ii	Left、Top Right、Centre	
Border	Switch on/off the border	ON,OFF	

*1 Multi-screen settings

Selecting the button Source in Multi-screen for the Multi-screen settings to be adjustable; some menus are hidden in Multi-screen;


When Multi-screen is selected for the channel, the quantization range, colour gamut, gamma, UMD and Payload ID of each screen can be adjusted separately.


*2 Multi-screen type


If there is no signal on the 4th SDI channel, an HDMI signal appears on the 4th channel.

Size

Monitor (unit:mm)







Specification

LCD Per	formance							
Model		BM-H215	BM-H215HDR	BM-H245				
Size	Size 21.5 inch 21.5英寸 23.8 inch							
Display ar	rea	476.064×267.786mm	476.064×267.786mm	527.04×296.46mm				
Resolutio	n	1920×1080	1920×1080	1920×1080				
Display Co	olor	16.7M	16.7M	16.78M				
Display ra	tio	16:9	16:9	16:9				
Brightnes	S	400cd/m ²	1000 cd/m ²	400cd/m ²				
Contract		1000:1	1000:1	1000:1				
Viewing A	ngle	H/V: 178°/178°	H/V: 178°/178°	H/V: 178°/178°				
Input /C	Output							
	BNC×4	12G/6G/3G/HD/SD-SDI×1,	6G/3G/HD/SD-SDI×3					
	HDMI×1	HDMI input						
Input	RS-485×2	GPI×1,UMD×1						
	USB×1							
ETHERNRT								
BNC×2		6G/3G/HD/SD-SDI×2						
Output	RS-485×1	UMD×1						
Other s _l	pecification							
Working v	oltage	AC:100V~240V DC/Battery:12V~17V						
Power cor	nsumption	≤60W						
Working t	emperature	0°C∼+50°C						
Working h	umidity	10%~90%						
Storage temperature		- 15°C∼ + 60°C						
Storage h	umidity	10%~90%						
Dimensio	ns (mm)	531×364×67.00mm	529×363×73mm	581×392×67mm				
Net weigh	t (w/o stand)	6.6KG	7.28KG	7.8KG				
Packing w	eight included	10KG	9.36KG	10.7KG				

Supported Format: Signals below can display on the monitor

		Input terminal				Signal format shown in the Status Display as		
No.	Format	SDI1	SDI 2/3/4	Quadlink SDI	HDMI	SDI1 out	SDI2 out	НДМІ
1	720×480/60I		_	_	_	_	_	_
2	720×480/60P	√	√	_	√	720*480P60	720*480P60	720*480P60
3	720×576/50I	_	_	_	_	_	_	_
4	720×576/50P	√	√	_	√	720*576P50	720*576P50	720*576I50
5	1280×720/23.98P	√	√	_	√	1280*720P23.98	1280*720P23.98	1280*720P24
6	1280×720/24P	√	√	_	√	1280*720P24	1280*720P24	1280*720P24
7	1280×720/25P	√	√	_	√	1280*720P25	1280*720P25	1280*720P25
8	1280×720/29.97P	√	√	_	√	1280*720P29.97	1280*720P29.97	1280*720P30
9	1280×720/30P	√	√	_	√	1280*720P30	1280*720P30	1280*720P30
10	1280×720/50P	√	√	_	√	1280*720P50	1280*720P50	1280*720P50
11	1280×720/59.94P	√	√	_	√	1280*720P59.94	1280*720P59.94	1280*720P60
12	1280×720/60P	√	√	_	√	1280*720P60	1280*720P60	1280*720P60
13	1920×1080/50I	√	√	_	√	1920*1080 50	1920*1080 50	1920*1080 50
14	1920×1080/59.94I	√	√	_	√	1920*1080 59.94	1920*1080 59.94	1920*1080 60
15	1920×1080/60I	√	√	_	√	1920*1080 60	1920*1080 60	1920*1080 60
16	1920×1080/23.98PSF	√	√	_	√	1920*1080PSF23.98	1920*1080PSF23.98	1920*1080PSF24
17	1920×1080/24PSF	√	√	_	√	1920*1080PSF24	1920*1080PSF24	1920*1080PSF24
18	1920×1080/23.98P	√	√	_	√	1920*1080P23.98	1920*1080P23.98	1920*1080P24
19	1920×1080/24P	√	√	_	√	1920*1080P24	1920*1080P24	1920*1080P24
20	1920×1080/25P	√	√	_	√	1920*1080P25	1920*1080P25	1920*1080P25
21	1920×1080/29.97P	√	√	_	√	1920*1080P29.97	1920*1080P29.97	1920*1080P30
22	1920×1080/30P	√	√	_	√	1920*1080P30	1920*1080P30	1920*1080P30
23	1920×1080/48P	√	√	_	√	1920*1080P48	1920*1080P48	1920*1080P48
24	1920×1080/50P	√	√	_	√	1920*1080P50	1920*1080P50	1920*1080P50
25	1920×1080/59.94P	√	√	_	√	1920*1080P59.94	1920*1080P59.94	1920*1080P60
26	1920×1080/60P	√	√	_	√	1920*1080P60	1920*1080P60	1920*1080P60
27	2048×1080/23.98PSF	√	_	_	√	2048*1080PSF23.98	_	2048*1080PSF24
28	2048×1080/24PSF	√	_	_	√	2048*1080PSF24	_	2048*1080PSF24
29	2048×1080/25PSF	√	_	_	√	2048*1080PSF25	_	2048*1080PSF25
30	2048×1080/29.97PSF	√	_	_	√	2048*1080PSF29.97	_	2048*1080PSF30
31	2048×1080/30PSF	√	_	_	√	2048*1080PSF30	_	2048*1080PSF30
32	2048×1080/23.98P	√	_	_	√	2048*1080P23.98	_	2048*1080P24
33	2048×1080/24P	√	_		√	2048*1080P24	_	2048*1080P24
34	2048×1080/25P	√	_	_	√	2048*1080P25	_	2048*1080P25
35	2048×1080/29.97P	√	_	_	√	2048*1080P29.97		2048*1080P30
36	2048×1080/30P	√	_		√	2048*1080P30		2048*1080P30
37	2048×1080/47.94P	√	_		√	2048*1080P47.94	_	2048*1080P50
38	2048×1080/48P	√	_	_	√	2048*1080P48	_	2048*1080P48
39	2048×1080/50P	√	_	_	√	2048*1080P50	_	2048*1080P50

			Input terminal			Signal format shown in the Status Display as		
No.	Format	SDI1	SDI2/3/4	Quadlink SDI	HDMI	SDI1 out	SDI2 out	HDMI
40	2048×1080/59.94P	√	_	_	√	2048*1080P59.94	_	2048*1080P60
41	2048×1080/60P	√	_	_	√	2048*1080P60	_	2048*1080P60
42	3840×2160/23.98P	√	_	√	√	3840*2160P23.98	_	3840*2160P24
43	3840×2160/24P	√	_	√	$\sqrt{}$	3840*2160P24	_	3840*2160P24
44	3840×2160/25P	√	_	√	√	3840*2160p25	_	3840*2160p25
45	3840×2160/29.97P	√	_	√	√	3840*2160P29.97	_	3840*2160P30
46	3840×2160/30P	√	_	√	√	3840*2160P30	_	3840*2160P30
47	3840×2160/47.94P	√	_	√	√	3840*2160P47.94	_	3840*2160P50
48	3840×2160/48P	√	_	√	√	3840*2160P48	_	3840*2160P48
49	3840×2160/50P	√	_	√	√	3840*2160P50	_	3840*2160P50
50	3840×2160/59.94P	√	_	√	√	3840*2160P59.94	_	3840*2160P60
51	3840×2160/60P	√	_	√	√	3840*2160P60	_	3840*2160P60
52	4096×2160/23.98P	√	_	√	\checkmark	4096*2160P23.98	_	4096*2160P24
53	4096×2160/24P	√	_	√	√	4096*2160P24	_	4096*2160P24
54	4096×2160/25P	√	_	√	√	4096*2160P25	_	4096*2160P25
55	4096×2160/29.97P	√	_	√	√	4096*2160P29.97	_	4096*2160P30
56	4096×2160/30P	√	_	√	√	4096*2160P30	_	4096*2160P30
57	4096×2160/47.94P	√	_	√	√	4096*2160P47.94	_	4096*2160P48
58	4096×2160/48P	√	_	√	$\sqrt{}$	4096*2160P48	_	4096*2160P48
59	4096×2160/50P	√	_	√	√	4096*2160P50	_	4096*2160P50
60	4096×2160/59.94P	√	_	√	√	4096*2160P59.94	_	4096*2160P60
61	4096×2160/60P	√		√	\checkmark	4096*2160P60		4096*2160P60

3G supports level A/levelB; Support RGB444

^{√:} The format is supported

^{—:} The format is not supported

Trouble-shooting

symptom	Possible causes	Solution		
	The power is not turned on	Please check if the power is connected, and then press "POWER" button to turn on the monitor		
	Unstable power voltage	Reconnect to power supply		
No display	BNC or HDMI cable loose contact or not correctly connected	Check and correctly connect the BNC or HDMI cable		
	The attached battery is no power	Change battery		
	Using DIY power supply but the polarity is reversed	Refer to the provided power supply, reconnect the power.		
	Bad contact of BNC or HDMI cable	Change the Video cable		
	Video signal has Interference	Remove the interference source(s)		
	Improper adjustment of the color parameters	Adjust the "Recall profile" to "Default" under "System" submenu		
Image or	Distortion of the image	Reset the Aspect ratio		
color abnormal	Set to Blue only	Turn off the "pure color " setting		
	Turn on the "Focus Assist" function	Turn off the "Focus Assist" function		
	Turn on the "False Color" function	Turn off the "False Color" function		
No audio	Set mute state	Cancel mute state or spin "MENU/ENTER" to adjust volume		
output	Bad contact of signal cable	Change signal cable		
	Wrong connection or bad contact of Audio cable	Connect to the correct input socket		



SWIT Electronics Co., Ltd.

Add: 10 Hengtong Road, Xin'gang, Nanjing Economic and Technological Development Zone, Nanjing 210038, P.R.China

Tel: +86-25-85805753 Email: contact@swit.cc

SWIT Electronics Europe GmbH

Add: Hochstr. 17, 47228 Duisburg, Germany

Tel: +49(0)20659799339 Email: info@swit-europe.com

SWIT Electronics America, Inc

Add: 3350 Scott Boulevard 61-02, Santa Clara, CA 95054, USA Tel: (408)260-8258, 1-866-986-SWIT(7948) Email: info@swit.us